





© Panduit Corp. 2022

INSTALLATION INSTRUCTIONS

FS198


Component included







Fiber Spool Installation & Removal


- · Install buttons on the back of the Fiber Spool into the keyholes in equipment
- Push Fiber Spool downward until a clicking sound is heard and Fiber Spool is completely engaged
- Removal Use one hand to pull top tab of the Fiber Spool out while simultaneously pushing spool upward







Fiber Spool Removal



For Instructions in Local Languages and Technical Support:



E-mail: techsupport@panduit.com Phone: 866-405-6654